

FRONTAL service columns

Frontal service columns. Installable on walls or like a delivery corner, they are connected with the centralized distribution system to work as an independent operational stations.




Comfort and ergonomics also in narrow spaces




Suitable for FCS system




Ceiling or floor installation









MAX NUMBER OF REELS CAN BE INSTALLED FOR SERIES										
Series	SWIVELLING				FIXED					
	250	260	280	300	290	330	390	430	450	530
P/N 39334	2	2	2	2	4	4	4	4	4	4
P/N 39335	2	2	2	2	5	5	5	5	5	5

ACCESSORIES

P/N 88630 Modular drip-tray equipped with hook for gun and removable drip-tray.

